

Traditional Hollow Metal Door Sizes to Strongdor Frame Sizes.



This guide explains how to convert traditional hollow metal door sizes or rough opening dimensions into the correct Strongdor frame sizes. By understanding these simple conversion steps, you can ensure a precise fit and smoother installation for your Strongdor door system.

NOMINAL DOOR SIZE	TRADITIONAL ROUGH OPENING SIZE	STRONGDOR FRAME WIDTH	STRONGDOR FRAME HEIGHT (IF EXISTING HAD 2" HEAD)	STRONGDOR FRAME HEIGHT (IF EXISTING HAD 4" HEAD)
2'0" x 6'8"	30" x 82"	29.5	81.75	83.75
2'4" x 6'8"	34" x 82"	33.5	81.75	83.75
2'6" x 6'8"	36" x 82"	35.5	81.75	83.75
2'8" x 6'8"	38" x 82"	37.5	81.75	83.75
2'9" x 6'8"	39" x 82"	38.5	81.75	83.75
3'0" x 6'8"	40" x 82"	39.5	81.75	83.75
3'4" x 6'8"	44" x 82"	43.5	81.75	83.75
3'6" x 6'8"	46" x 82"	45.5	81.75	83.75
3'8" x 6'8"	48" x 82"	47.5	81.75	83.75
4'0" x 6'8"	4'0" x 82"	49.5	81.75	83.75
2'0" x 7'0"	30" x 86"	29.5	85.75	87.75
2'4" x 7'0"	34" x 86"	33.5	85.75	87.75
2'6" x 7'0"	36" x 86"	35.5	85.75	87.75
2'8" x 7'0"	38" x 86"	37.5	85.75	87.75
2'9" x 7'0"	39" x 86"	38.5	85.75	87.75
3'0" x 7'0"	40" x 86"	39.5	85.75	87.75
3'4" x 7'0"	44" x 86"	43.5	85.75	87.75
3'6" x 7'0"	46" x 86"	45.5	85.75	87.75
3'8" x 7'0"	48" x 86"	47.5	85.75	87.75
4'0" x 7'0"	50" x 86"	49.5	85.75	87.75
3'0" x 8'0"	40" x 98"	39.5	97.75	99.75
3'6" x 8'0"	46" x 98"	45.5	97.75	99.75
4'0" x 8'0"	50" x 98"	49.5	97.75	99.75
6'0" x 6'8" Pair	76" x 82" Pair	75.5	81.75	83.75
6'0" x 7'0" Pair	76" x 86" Pair	75.5	85.75	87.75